

INSTALLATION GUIDE

ABS sealant collar extension
Prod. No. ZU-V-XX-XXX



1.

Put the shrink tubing onto the sealant collar.



2.

Use heat to shrink the tubing
(e.g. hot air gun).

Always start at the bottom!



3.

Once the bottom edge has
been completely shrunk on
work your way up.

Important: Work your way very
carefully upwards, starting at
the bottom, to avoid pockets
of air and leaks!



4.

The shrink tubing is watertight
if adhesive has been pushed
out at both ends.

